



# 7½ ft. ROLLING CHRISTMAS TREE STORAGE BAG

MODEL #: SB-10141


IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

For assistance with assembly, replacement parts or to activate your warranty:  
www.SantasBags.com | Support@VillageLighting.com

2018 All Rights Reserved \* Property of Village Lighting Co. | Intended for indoor use

## How to Load your Christmas Tree

Make sure your tree is disassembled and the sections are fully compressed.







Three Section Tree




Four Section Tree




Five Section Tree




1 Disassemble your tree and fully compress the sections.



2 Insert the largest tree section with the trunk facing the wheels.




3 Insert the next largest tree section opposite of the first.



4 Insert the tree top and stand in the remaining space.

### WARNING



To avoid tearing the bag with your tree trunk make sure to place trunk centered in the bottom of the bag near the wheels.